



LIV12HP230V1R32AH

| No. | Part Description | Qty | |
|------|------------------------|-----|----------------|
| 1 | Rear Case Sub-Assy | 1 | 00037706008901 |
| 2 | Air Louver(Left) | 1 | 200007060111 |
| 3 | Air Louver(Right) | 1 | 200007060110 |
| 4 | Swing Lever | 1 | 200035060044 |
| 5 | Air Louver (Auto) | 1 | 200007060117 |
| 6 | Stepping Motor | 1 | 1521210704 |
| 7 | Rear Grill Sub-assy | 1 | 209168000016 |
| 8 | Rear Grill Sub-assy | 1 | 209168000016 |
| 9 | Axile Bush Sub-assy | 1 | 10542047 |
| 10 | Cross Flow Fan | 1 | 103001060038 |
| 11 | Fan Motor | 1 | 15010406011702 |
| 13 | Drainage Hose | 1 | 05230014 |
| 14 | Evaporator Assy | 1 | 01100106240507 |
| 15 | Evaporator Support | 1 | 200025060027 |
| 16 | Electric Box Assy | 1 | 100002082382 |
| 16-1 | Electric Box | 1 | 200013060124 |
| 16-2 | Main Board | 1 | 300002064066 |
| 16-3 | Jumper | 1 | 4202021907 |
| 16-4 | Display Board | 1 | 300001061554 |
| 16-5 | Terminal Board | 1 | 422000000022 |
| 16-6 | Temperature Sensor | 1 | 3900031302 |
| 17 | Front Case Assy | 1 | 000002060324 |
| 17-1 | Front Case | 1 | 200002060087 |
| 17-4 | Filter Sub-Assy | 1 | 111001060341 |
| 19 | Guide Louver | 1 | 200004060197 |
| 20 | Stepping Motor | 1 | 1521210712 |
| 22 | Axile Bush | 1 | 10542036 |
| 23 | Front Panel | 1 | 200003060306T |
| 24 | Electric Box Cover | 1 | 200082060091 |
| 25 | Wall Mounting Frame | 1 | 012043000008 |
| 27 | Remote Controller | 1 | 305001060236 |
| 29 | R32 Refrigerant Sensor | 1 | 34002406001601 |