



序号	英文名称	中文名称	备注
48	Sensor Sub-assy	温度感测器 (电子版)	*
47	Electrical Heater	电加热管	*
46	Electrical Heater/Compressor	电加热管	*
45	Magnet Coil (electromagnetic start)	电磁线圈	*
44	Magnet Coil (electromagnetic start)	电磁线圈	*
43	4 Way Valve Coil	四通阀线圈	*
42	Electric Expansion Valve Filling	电子膨胀阀注液	*
41	Electric Expansion Valve Filling	电子膨胀阀注液	*
40	Electric Expansion Valve Filling	电子膨胀阀注液	*
39	Rear Grid	后背罩	*
38	Condenser Assy	冷凝器总成	*
37	Electromagnetic Valve	电磁阀	*
36	Strainer	过滤器	*
35	Pressure Sensor	压力传感器	*
34	4 Way Valve	四通阀	*
33	Strainer	过滤器	*
32	Strainer	过滤器	*
31	Plate-type Heat Exchanger	板式换热器	*
30	Cut off Valve	截止阀	*
29	Electronic Expansion Valve	电子膨胀阀	*
28	Electronic Expansion Valve	电子膨胀阀	*
27	Electronic Expansion Valve	电子膨胀阀	*
26	Electronic Expansion Valve	电子膨胀阀	*
25	Strainer	过滤器	*
24	Filter Board	过滤器板	*
23	Filter Board	过滤器板	*
22	Filter Board	过滤器板	*
21	Filter Board	过滤器板	*
20	Filter Board	过滤器板	*
19	Filter Board	过滤器板	*
18	Filter Board	过滤器板	*
17	Main Board	主板	*
16	Terminal Board	端子板	*
15	Electric Wire Assy	电气线束总成	*
14	Pressure Sensor	压力传感器	*
13	Pressure Protect Switch	压力保护开关	*
12	Compressor and Filings	压缩机及吸油毡	*
11	Oil Separator	油分离器	*
10	Discharge Charge Valve	排液阀	*
9	Electronic Expansion Valve	电子膨胀阀	*
8	Chassis Sub-assy	底盘组件	*
7	Front Grid	前罩	*
6	Handle	把手	*
5	Front Side Plate	前面板	*
4	Brushless DC Motor	无刷直流电机	*
3	Brushless DC Motor	无刷直流电机	*
2	Left Side Plate	左面板	*
1	Casing	外壳	*

标记	比例	数量	比例
零件	1:1	1	1:1
工艺	数量	共 1 页	第 1 页
名称	数量	YH09LCTL 2300000	



GMV-V48WL/C-T(U)

No.	Parts Description	Qty	Part Code
12	Discharge Charge Valve	1	'071015000002
11	Electronic Expansion Valve/DPF(B)3.2C-015	1	'072009060008
19	Electric Box Assy	1	'100002078277
NS	Nut with Washer	1	'70310165
22	Main Board/WZ6A05F	1	'300027063015
NS	Relay 40A	1	'441001000012
24	Filter Board ZLB87A	1	'300020060111
20	Terminal Board (2 digits)	1	'42200006001202
21	Terminal Board (4 bits)	1	'42200006005403
NS	Overcurrent Circuit Breaker/NDB2T-63D63/2	1	'43003106000915
NS	Jumper (Gray)	1	'30000300000402
NS	Jumper (Blue)	1	'4202021901
NS	Temperature Sensor clamp	1	'02145007
48	Sensor Sub-Assy	1	'390002060389
41	Electric Expand Valve Fitting	1	'07200206002002
40	Electronic Expansion Valve Coil UKV	1	'4304413251
42	Electronic Expansion Valve Coil UKV	1	'4304413261
43	4 Way Valve Coil	1	'07201006000604
45	Electromagnetic Valve Coil/208-230V60Hz800	1	'07200106001532
44	electromagnetic Valve Coil208-230v60Hz1400	1	'07200106001523
46	Electrical Heater (Compressor)	1	'7651521216
NS	Heat Insulating Hose	1	'75088203
NS	Heat Insulator	9	'12128748
18	Connection Board	1	'012077060725P
NS	Right Side Plate	1	'012056060338P
8	Handle	1	'20014906000302
2	Left Side Plate	1	'012055060285P
NS	Cabinet Assy	1	'000006060205
7	Cabinet	1	'012022060009P
9	Front Grill	2	'016004060002
NS	Rubber ring (wire-passing)	1	'76712049
6	Front Side Plate	1	'012050060023P
8	Handle	1	'20014906000302
NS	Top Cover Sub-Assy	1	'000051060231
1	Coping	1	'012049060098P
39	Rear Grille	1	'01574100004
NS	Drainage Joint	1	'06123401
NS	Plastic Cap	1	'7671013101
NS	Packaging Foam	1	'52064100003
NS	Drainage Hole Cap	3	'06813401